

FIG. 1




FIG. 2A








FIG. 2B

T00220" 2696860

FIG. 2C



5/8

FIG. 2D*FIG. 3*

6/8

FIG. 4





FIG. 5



7/8

FIG. 6A

AT THE TIME OF CD-CH CONTROL

OPERATION	ACTION
①	TRACK DOWN
②	TRACK UP
③	DISK DOWN
④	DISK UP
⑤ ⑦	VOLUME UP
⑥ ⑧	VOLUME DOWN

FIG. 6B

AT THE TIME OF TUNER CONTROL

OPERATION	ACTION
①	SEEK DOWN
②	SEEK UP
③	AM BAND SWITCH
④	FM BAND SWITCH
⑤ ⑦	VOLUME UP
⑥ ⑧	VOLUME DOWN


FIG. 6C

FIG. 7